




# Single Duct Variable Air Volume (VAV) Terminal Unit

## Cooling Only

### Pressure Independent

#### Model: BAC-8001

If controllers are to be networked together, turn **ON** EOL dip switches on the controllers at both physical ends of the network. Connect shield to earth ground at only one point.




#### NOTES:

1. Controller settings must be initially set using an STE-8XXX.
2. See SimplyVAV.com for accessories and additional details.

#### SEQUENCE OF OPERATION:

1. As space temperature rises above the cooling setpoint, the controller increases airflow. At a space temperature of 2°F above the cooling setpoint, maximum cooling airflow is maintained. On a decrease in space temperature, the controller reduces airflow. Below cooling setpoint, minimum cooling airflow is maintained.



© 2014 KMC CONTROLS, INC.



KMC CONTROLS, INC.  
19476 INDUSTRIAL DR.  
NEW PARIS, IN 46553  
PHONE: 574.831.5250  
FAX: 574.831.5252  
SimplyVAV.com

DRAWING TITLE: COOLING ONLY VAV

CREATION DATE: 3/7/2014

FILENAME: SS14001A\_SimplyVAV\_CLG

REVISION DATE: 3/7/2014

REVISION: INITIAL RELEASE